



iControl K06-US

6 Keys Control Keypad, US version

User Manual V1.0



TABLE OF CONTENTS

SAFETY PRECAUTIONS	3
1. INTRODUCTION	4
2. FEATURES	4
3. PACKAGE LIST	4
4. PANEL DESCRIPTION	5
5. SYSTEM CONNECTION	6
6. GUI CONTROL	7
6.1 LOG IN	7
6.2 HOME	8
6.3 CONFIGURATION	9
6.3.1 <i>Knob</i>	9
6.3.2 <i>BUTTON</i>	10
6.3.3 <i>TCP/IP</i>	10
6.3.4 <i>RS232</i>	11
6.3.5 <i>IR</i>	12
6.3.6 <i>RELAY</i>	12
6.3.7 <i>LED</i>	13
6.3.8 <i>DELAY</i>	14
6.4 NETWORK	14
6.5 SETTING	15
6.6 UPGRADE	15
7. SPECIFICATION	16
8. PANEL DRAWING	17
9. CUSTOMER SERVICE	18

SAFETY PRECAUTIONS

- To insure the best from the product, please read all instructions carefully before using the device. Save this manual for further reference.
- Unpack the equipment carefully and save the original box and packing material for possible future shipment.
- Follow basic safety precautions to reduce the risk of fire, electrical shock and injury to persons.
- Do not dismantle the housing or modify the module. It may result in electrical shock or burn.
- Using supplies or parts not meeting the products' specifications may cause damage, deterioration or malfunction.
- Refer all servicing to qualified service personnel.
- To prevent fire or shock hazard, do not expose the unit to rain, moisture or install this product near water.
- Do not put any heavy items on the extension cable in case of extrusion.
- Do not remove the housing of the device as opening or removing housing may expose you to dangerous voltage or other hazards.
- Install the device in a place with fine ventilation to avoid damage caused by overheating.
- Keep the module away from liquids.
- Spillage into the housing may result in fire, electrical shock, or equipment damage.
- If an object or liquid falls or spills on to the housing, unplug the module immediately.
- Do not twist or pull by force ends of the optical cable. It can cause malfunction.
- Do not use liquid or aerosol cleaners to clean this unit. Always unplug the power to the device before cleaning.
- Unplug the power cord when left unused for a long period of time.
- Information on disposal for scrapped devices: do not burn or mix with general household waste, please treat them as normal electrical wastes.



1. INTRODUCTION

The **iControl K06-US** Wallplate Control Panel has 2x built-in programmable RS232 connectors and 2x Infrared (IR) connectors.

The Programmable Control Panel can fully control the compatible switches, as well as third-party devices such as matrix switcher, compact scaler switcher, projectors, screens, etc. Use the device for presentations in showrooms, classrooms, and boardrooms.


2. FEATURES

- 6x programmable backlit buttons w/ customizable label
- Each button color can be customized by user
- 1x volume control knob
- 2 RS-232, 2 IR and 2 Relay for control.
- Support TCP/IP Control
- Support IR learning function
- Can be controlled and configured via User-friendly Web GUI
- Can be powered by PoE
- US Wallplate version


3. PACKAGE LIST

- 1x iControl K06-US
- 1x 2-Pin Pluggable terminal blocks
- 6x Button caps
- 1x 5-Pin Pluggable terminal block
- 2x 3-Pin Pluggable terminal block
- 1x Button label
- 1 x User Manual

4. PANEL DESCRIPTION




No.	Name	Description
1	Power LED	Illuminates green when power on.
2	Volume Knob	Black volume knob, high-quality knob with high damping feel and stable structure, about 12-13mm in diameter
3	Button	6x crystal and luminescent programmable buttons: Each button can be programmed with the Web GUI. Each label within a button can be easily changed. Simply select the label you need and change it as shown below:

		
4	Volume indicator	5x blue indicator lights, light up in percentage according to the volume knob (1-19%, 20-39%, 40-59%, 60-79%, 80-100%)
5	TCP/IP	RJ45 connector. Connects with PC to run the GUI to customize button control.
6	RESET	Long-press this button 3 seconds until the power LED goes out to start to the restore factory defaults, and then the LED will light up while the resetting is successful.
7	IR Sensor	Receives and learns the IR code to build the IR database.
8	PWR(12V)	Connects with 12V DC power adaptor.
9	RELAY	2x groups of Relay Control, share a common switch interface, default ON
10	IR	2x sets of IR OUT, share a ground port, 5V standard, connect to the infrared emitting rod
11	RS232	2x RS232 ports. Connect the third-party devices which are need to be controlled via the iControl K06-US .

5. SYSTEM CONNECTION

The **iControl K06-US** can active different ports at one time. It means every button can send the RS232 commands, IR code at the same time.

The demo system diagram as below:



- 1) Connect the **iControl K06-US** to the LAN port of Wireless Router/ network switch/ control device (such as PC) to TCP/IP port.
- 2) Connect the third-party devices (such as Matrix Switcher, Compact Scaler Switcher or Projector) that need to be controlled to RS232 (1) ~RS232 (2) ports.
- 3) Connect the IR Emitters to IR (1) ~ IR (2) ports.
- 4) Connect to the third-party devices that need to be controlled by relay.

6. GUI CONTROL

6.1 LOG IN

The **iControl K06-US** is controlled by TCP/IP. The default settings are:

IP Address: 192.168.0.178

Subnet Mask: 255.255.255.0

Telnet port: 4001

Type 192.168.0.178 in the internet browser, it will enter the below log-in webpage:




Username: admin

Password: admin

Type the username and password, and then click the login to enter the GUI setting.


6.2 HOME



- Click the volume icon to adjust the volume; or click the knob icon to implement the corresponding event;
- Mouse operation click the corresponding button


6.3 CONFIGURATION

6.3.1 KNOB




- **Knob/Button:** Choose the knob or button to enter the event setting page.
- **Start up:** Click to enter the starts up event setting page.
- **Set the Knob events:** Turn Left, Press Down Setting or Turn Right

6.3.2 BUTTON




- Click the Button 1 to set the button 1 event, click **Add Event** and then set the Event and the corresponding settings.
- One button can set multiple command events, such as TCP/IP, RS232, IR, RELAY, Delay and LED status.

6.3.3 TCP/IP




- Set the TCP/IP event, such as IP, Port, Format, End Char for ASCII and Data

6.3.4 RS232




- Set the RS232 event, and then click save button to finish setting.

6.3.5 IR




- In IR event, user can import or export the IR command.
- Set the Event Name, Port, Code or Custom and IR Code for the event.
- Click Save button to finish setting.

6.3.6 RELAY



- Set the Event Name, Port and the Action Mode.
- Click Save button to finish setting.

6.3.7 LED




The screenshot shows the iControl K06 web interface. The top navigation bar has tabs for Home, Configuration (which is highlighted in blue), Network, Setting, and Upgrade. On the left, there's a sidebar with a 'Knob' option and a list of buttons: Button 1 (selected and highlighted in blue), Button 2, Button 3, Button 4, Button 5, Button 6, Button 1 + 2, Button 3 + 4, and Button 5 + 6. Below this is a 'Start Up' button. The main content area is titled 'Add Event' and shows the following configuration for an LED event:

- Event: LED
- Event Name: Event Name
- Button Select: Button 1
- Status: Always OFF

At the bottom of the main area are 'Save' and 'Cancel' buttons. The footer of the page includes 'Log Off', the device name 'iControl K06', and the infobit logo.


- Set the Event Name, Button Select, Status and LED Color.
- Click the Save button to finish setting.

6.3.8 DELAY




- Set the delay event to trigger the event after how long to press.
- Click Save button to finish setting.

6.4 NETWORK




- Select dynamic or static IP mode. Under static mode, then IP Address, Subnet Mask and Gateway can be reset.

6.5 SETTING



- **Credentials:** setting the user name and new password and then click confirm button to perform the modification.
- **Update Profile:** Import or export the setting file to implement the system configuration.
- **Factory Default:** Click Factory reset.

6.6 UPGRADE




- Firmware Upgrade: click the browse to choose the upgrade file (the file need to be 6 Buttons IP Control Panel renamed as “K06.app”) and then click upgrade to execute upgrade.

7. SPECIFICATION

Model	iControl K06-US
Name	6 Keys Control Keypad, US version
Program Port	TCP/IP
Output Port	2x RS232, 2x IR, 2x Relay
Output Connector	2x 3-Pin Pluggable terminal blocks, 2x 2-Pin Pluggable terminal blocks
Baud Rate	9600 baud, supports 9600, 19200, 38400, 57600, 115200
Power Consumption	2.5W (Max)

Operation Temperature	0 ~ +40°C
Storage Temperature	-10 ~ +55°C
Relative Humidity	10% ~ 90%
Power Supply	Input: 12VDC, PoE
Net Weight	250g
Case Dimensions	70mm x 115mm x 50.5mm, WHD

8. PANEL DRAWING



9. CUSTOMER SERVICE

The return of a product to our Customer Service implies the full agreement of the terms and conditions hereinafter. These terms and conditions may be changed without prior notice.

1) Warranty

The limited warranty period of the product is fixed three years.

2) Scope

These terms and conditions of Customer Service apply to the customer service provided for the products or any other items sold by authorized distributor only.

3) Warranty Exclusions:

- Warranty expiration.
- Factory applied serial number has been altered or removed from the product.
- Damage, deterioration or malfunction caused by:
 - ✓ Normal wear and tear.
 - ✓ Use of supplies or parts not meeting our specifications.
 - ✓ No certificate or invoice as the proof of warranty.
 - ✓ The product model showed on the warranty card does not match with the model of the product for repairing or had been altered.
 - ✓ Damage caused by force majeure.
 - ✓ Servicing not authorized by distributor.
 - ✓ Any other causes which does not relate to a product defect.
- Shipping fees, installation or labor charges for installation or setup of the product.

4) Documentation:

Customer Service will accept defective product(s) in the scope of warranty coverage at the sole condition that the defect has been clearly defined, and upon reception of the documents or copy of invoice, indicating the date of purchase, the type of product, the serial number, and the name of distributor.

Remarks: For further assistance or solutions, please contact your local distributor.